

## 2008 Ford Focus

- 1) Remove snap in plastic knee panel
- 2) Remove 3 5.5 mm screws from underside of plastic column shroud.
- 3) Separate upper and lower plastic column shroud halves and remove upper shroud.
- 4) Locate 3 airbag/horn pad retainer clips (#1) on rear of wheel. Insert flat screwdriver or similar tool and rotate to remove pressure from spring loaded clip. 1/3 of airbag/hornpad should release. Continue with remaining 2 clips.
- 5) **Disconnect negative battery terminal.**
- 6) Disconnect Clock spring connector (#2). Disconnect 2 airbag connectors (#4). Disconnect horn plug (#5).
- 7) Remove steering wheel retainer bolt (#3).
- 8) Remove wheel with steering wheel puller (Carquest part #CPE39647)
- 9) Install new wheel. Reconnect plugs marked 2,4 and 5.
- 10) Reinstall Steering wheel retainer bolt (#3).
- 11) Replace airbag/hornpad by pressing gently into place.
- 12) Reconnect negative battery Terminal.
- 13) Program cruise features using Ford IDS scan tool.

