



2007 G-Van w/LED Tail lights

- 1) Locate Throttle Actuator Control Module (TAC) under hood at drivers side rear engine compartment.
- 2) Locate lt. blue brake circuit wire (pin 6) on connector 1.
- 3) Cut lt. blue wire aprox. 2-3 inches from module.
- 4) Connect red wire (#86) to brake switch side of cut lt. blue wire
- 5) Connect orange wire (87a) to module side of cut lt. blue wire
- 6) Connect Black & Yellow wires (#85 & 30) to known good vehicle chassis ground
- 7) Install OEM cruise switch
- 8) Test drive vehicle.

1-800-343-1382