



2004 to 2006 Scion : Instructions for RF Switch installation

- 1) Disregard step 10 in Scion cruise instructions.
- 2) Connect 4 pin RF switch plug to corresponding cruise 4 pin plug (all pin colors will match up).
- 3) Connect brown wire from RF switch to brown wire from cruise kit
- 4) Ground RF switch black wire.
- 5) Install RF switch bracket below horn pad on steering wheel at the 4 o'clock position. There is a small seam where horn pad and steering wheel meet. Insert bracket into seam and push down towards column.
- 6) Install switch on bracket.

Please contact The Cruise Control Store for any technical questions

1-800-343-1382