



1997-2006 All Gas Engines & 2007 w/4.3 V6

Cruise Violet wire to vehicle White wire = at vehicles brake switch on brake pedal

Cruise Red wire to vehicle Orange wire = at vehicles brake switch on brake pedal

Cruise Brown wire to vehicle Pink ignition wire = at ignition switch

Cruise Black & Blue wires to ground

Cruise Gray wire to vehicles VSS output as follows :

1997-2000 Pin #3 of 24 pin connector at Vehicles VCM (Engine compartment – Left Fender) or Pre-wired Cruise connector Pin K Left Fender (connector is not always present).

2001-2006 & 2007 V6 Pin #50 of 80 pin connector at vehicles PCM (Engine compartment – Left Fender)
Vehicle wires on both sides of Pin #50 are Yellow with a black stripe. Also can be found at Pre-wired cruise connector Pin K, Left Fender (connector is not always present).

V6 Dip switch settings

1=on	7=off
2=off	8=on
3=on	9=off
4=off	10=on
5=off	11=on
6=off	12=off

V8 Dip Switch settings

1=on	7=off
2=off	8=off
3=on	9=off
4=off	10=on
5=off	11=on
6=off	12=off

1-800-343-1382