

## Ford Focus 2000-2007

Cruise Violet wire to vehicle Green/Red wire = at vehicles brake switch on brake pedal

On manual transmission models this violet wire will go to 1 of 2 violet wires at our clutch switch and remaining violet clutch switch wire will go to the vehicles Green/Red wire

Cruise Red wire to vehicle Green/white wire = at vehicles brake switch on brake pedal

Cruise Brown wire to vehicle Yellow ignition wire = at ignition switch

Cruise Gray wire to vehicles VSS ouput as follows:

**2000** models with 2.0 engine = pin 28 of ECM 104 pin connector ( Passenger kick panel ): vehicle wire color = white/green

**2001-2004** with 2.0 engine = pin 28 of ECM 104 pin connector ( Passenger Kick panel ) : vehicle wire color = white/violet

**2002-2004** with 2.3 engine = pin 1 of middle connector of ECM ( Passenger kick panel ) : vehicle wire color = white/violet

**2005-2007** all engines = pin 1 of middle connector of ECM ( Passenger kick Panel ) : vehicle wire color = white/violet

## Dip switch settings

1=on	7=on
2=off	8=off
3=on	9=off
4=on	10=on
5=off	11=on for auto off for manual
6=off	12=off

1-800-343-1382