



2011-2012 F-150 & SuperDuty Cruise Programming Instructions
Using IDS with V75 or Higher

GAS MODELS

- 1) ID Vehicle
- 2) Choose TOOL BOX then MODULE PROGRAMMING then PROGRAMMABLE PARAMETERS then SPEED ITEMS
- 3) Choose CRUISE CONTROL SWITCH (SCMM) then set to ENABLED
- 4) Choose SPEED CONTROL (BDYCM) then set to ENABLED
- 5) Programming Complete

DIESEL MODELS

- 1) ID Vehicle
- 2) Choose TOOL BOX then MODULE PROGRAMMING then PROGRAMMABLE PARAMETERS then SPEED ITEMS
- 3) Choose CRUISE CONTROL (SCCM) then set to ENABLED
- 4) Choose SPEED CONTROL (BDYCM) then set to ENABLED
- 5) Choose SPEED CONTROL (PCM) then set to PRESENT
- 6) Choose SPEED CONTROL SYSTEM TYPE (PCM) then set to CRUISE CONTROL
- 7) Programming Complete.