

## TOYOTA TACOMA 1995-2004 ALL

\*Brake Hot = Green/yellow: Located at vehicles brake switch mounted on brake pedal : Cruise wire = Red

\*Brake Cold= Green/white: Located at vehicles brake switch mounted on brake pedal. On automatic models the cruise violet wire will connect here. \*\* On manual transmission models, Violet clutch wire #2 will connect here \*\*

\*VSS Wire = Green/Orange at PCM

1995-1997 2.4 = Pin #9 of 22 pin connector

1998-2000 2.4 = Pin #8 of 22 pin connector

2001-2004 2.4 = Pin #21 of 22 pin connector

1995-1999 2.7 Auto = Pin #8 of 28 pin connector

1995-1996 2.7 Manual = Pin #9 of 22 pin connector

1997-1999 2.7 Manual = Pin #8 of 22 pin connector

2000 Auto & Manual 2.7 = Pin #8 of 22 pin connector

2001-2004 2.7 Auto & Manual = Pin #21 of 22 pin connector

1995-2000 3.4 Auto = Pin #12 of 28 pin connector

1995-1997 3.4 Manual = Pin #8 of 22 pin connector

1998-2000 3.4 Manual = Pin #12 of 28 pin connector

2001 3.4 Auto & Manual = Pin # 22 of 28 pin connector

2002-2004 3.4 Auto & Manual = Pin #6 of 22 pin connector

\*VSS Wire on California Emmisions for the 2000 model year

2.4 & 2.7 = Pin #21 of 28 pin connector

3.4 = Pin #22 of 28 pin connector

The clutch switch will have two violet wires. It does not matter which violet wire you use for either circuit. Connect them as follows;

**Violet wire #1** connect to violet wire from cruise control **Violet wire #2** connect to Green/white brake wire

Switch Settings for 2.4 & 2.7	Switch Settings for 3.4
1=on	1=on
2=off	2=off
3=on	3=on
4=on	4=on
5=off	5=off
6=off	6=off
7=on	7=off
8=off	8=on
9=off	9=off
10=on	10=on
11=on auto, off manual	11=on auto, off manual
12=off	12=off

Technical assistance Monday-Friday 8:30-5:00 Eastern Time 1-800-343-1382

<sup>\*</sup>Ignition Wire =  $_{Black/yellow}$  wire at vehicles ignition switch : cruise wire = brown

<sup>\*</sup>Tach wire = connect directly to chassis ground : Cruise wire = Blue

<sup>\*</sup>Ground wire = connect directly to chassis ground : Cruise wire = Black with loop.

<sup>\*</sup>Clutch Switch wiring for manual transmission ONLY