

GENERAL APPLICABILITY

CHEVROLET CRUZE - AT & MT




KIT CONTENTS/SERVICE PARTS

ITEM	QTY	DESCRIPTION	PART#
1	1	CRUISE CONTROL MODULE	250-2860-A/T 250-2861-M/T
2	1	SWITCH HARNESS	250-2760
3	1	PEDAL INTERFACE HARNESS	250-2823
4	1	ANALOG HARNESS	250-2931
5	1	CONTROL SWITCH	250-3742
6	1	DIAGNOSTICS HARNESS	250-2785

1-800-343-1382

Please call for technical assistance. You will need your invoice number.



HARDWARE BAG CONTENTS

ITEM	QTY	DESCRIPTION
1	8	WIRE ZIP TIES
2		
3		

LEGEND



**STOP:** DAMAGE TO VEHICLE MAY OCCUR. DO NOT PROCEED UNTIL PROCESS COMPLIANCE HAS BEEN MET.



**OPERATOR SAFETY:** USE CAUTION TO AVOID RISK OF INJURY.



**CRITICAL PROCESS:** PROCEED WITH CAUTION TO ENSURE A QUALITY INSTALLATION. THESE POINTS WILL BE AUDITED ON A COMPLETED VEHICLE INSTALLATION.



**GENERAL PROCESS:** THIS HIGHLIGHTS SPECIFIC PROCESSES TO ENSURE A QUALITY INSTALLATION. THESE POINTS WILL BE AUDITED DURING THE ACCESSORY INSTALLATION.



**TOOLS & EQUIPMENT:** THIS CALLS OUT THE SPECIFIC TOOLS AND EQUIPMENT REQUIRED FOR THE PROCESS.



**REVISION MARK:** THIS MARK HIGHLIGHTS A CHANGE IN INSTALLATION WITH RESPECT TO PREVIOUS ISSUE.



**WARNING: DO NOT USE HAND-HELD 2-WAY TRANSCEIVERS INSIDE YOUR VEHICLE WHILE DRIVING.**

WHEN TRANSMITTING FROM INSIDE THE CAR, 2-WAY RADIOS THAT OPERATE IN THE 25MHZ-700MHZ FREQUENCY RANGE WITH MORE THAN 2.0 WATTS OF POWER CAN PRODUCE ELECTROMAGNETIC INTERFERENCE THAT COULD INTERFERE WITH THE OPERATION OF CRUISE AND THROTTLE CONTROLS RESULTING IN VEHICLE "LIMP MODE".

USE OF CELLULAR PHONES WILL NOT INTERFERE WITH THESE CONTROLS.



**DUE TO SENSITIVE NATURE OF SIGNALS USED FOR THIS PRODUCT, ALL NON-PLUG AND PLAY CONNECTIONS MUST BE SOLDERED. FAILURE TO COMPLY WITH THIS REQUIREMENT WILL VOID WARRANTY.**



## BEFORE INSTALLATION

To make the installation easier, the complete installation instructions should be read through before installation is started.

This installation instructions contains information how to install the Electronic Cruise Control which is not a Do-It-Yourself job.

Modern cars are equipped with electronics, which can be costly damaged by inappropriate treatment.

Rostra Precision Controls can not be held responsible for any error caused by wrong installation



## SOME GOOD ADVICE

Always disconnect the negative cable from battery before installation.

Always use the enclosed installation instruction for installing the Electronic Cruise Control.

Check the part number of the cruise module label is the same compared to the part number of the installation instructions.

Be aware of radio codes that might have to be typed in.

Find a location to install the cruise module and control switch


If any wires are left, then cut off and insulate.

Only use a multimeter to measure voltage.

Always drive the car for a complete test before assembling the car.

All wire leads must be soldered.

INSTALLATION



White  
Red  
Yellow  
Green  
Red

Ignition  
Red Wire

Black  
Red


Connect data harness  
cap to OBD2 connector

Optional \*Cut the Rostra connector off and solder wires: Red Wire to Pin 6, Black Wire to Pin 14

\*Optional



\*\*\* SEE PAGE #4  
if there is an  
unsuccessful test  
drive.


To OBD2  
Connector



SOLDER RED IGNITION WIRE FROM CRUISE HARNESS  
TO Yellow/Blue WIRE IN IGNITION SWITCH HARNESS  
LOCATED BELOW STEERING COLUMN

Connect to the  
accelerator  
pedal






Locate the Black 26 pin connector in BCM under drivers side dash panel.

**Connect cruise white/brown wire to ONLY violet/white wire in this connector. Should be position #11 or Position #15**


Locate the Black 26 pin connector in BCM under drivers side dash panel. Solder the Blue Wire to position 7 White/Yellow.

If Position #7 is blank, connect Blue wire to Cruise Red ignition wire.

\* If cruise does not work, sever OBDII connector off and extend RED and BLACK data wires to BCM. Locate WHITE CONNECTOR at bottom of BCM. Connect RED wire to PIN# 25 BLUE WIRE. Connect BLACK wire to PIN # 24 WHITE wire.



BCM under drivers side dash panel  
BLACK connector.



Switch Harness	Rostra Switch
BLACK	BLACK
BLUE/YELLOW	RED
BLUE/YELLOW*	BLUE*
RED/PURPLE	GREEN
BLACK/PURPLE	YELLOW
YELLOW/GREEN	BROWN

\* Both Blue/Yellow wires are spliced together. Just connect one BLU/YEL wire to the BLUE, and the other to the RED. The order does not matter.



**Do not drill hole for control switch before testing the cruise system**

